




Liquid Flow Controller

Quick Start Guide

Models LC, LCR, LCS, LCRS



A Halma company



Download the full manual: Alicat.com/manuals


Annual Calibration • Troubleshooting • Questions:

+91 (0)9930047455 • india@alicat.com

This box includes:

- Alicat device
- NIST traceable calibration certificate
- Optional accessories (cables, power adapters, filters)

Get Started:




Power

The power supply input is on top. Most devices require 12–24 Vdc and 1 A. See *Power and Signal Connections* in the manual for details.



Tare


Before installing the device, give your controller a 0 setpoint for at least 2 seconds, activating the auto tare feature and zero out (tare) your unit.




Units

Ensure the proper units are selected. Press **MENU** → **SETUP** → **SENSOR** → **ENGINEERING UNITS**.

You're Ready to Connect:



Ensure the flow direction is the same as the flow arrow. For applications that continuously add air bubbles, the device may be mounted upside-down, except for large valve controllers (LCR-Series).



Connect the device to your process, and start the flow of water. To remove air bubbles:

- set the device to its maximum setpoint,
- gently loosen the upstream bleed port screw, but stop when pressure forces liquid to leak,
- tap the flow body.

Do not use bleed ports if the device is inverted.

Download the full manual: [Alicat.com/manuals](https://www.alicat.com/manuals)

Annual Calibration • Troubleshooting • Questions:
+91 (0)9930047455 • india@alicat.com

