CERTIFICATE

Issued to: Applicant: Alicat Scientific 7641 N Business Park Dr Tucson AZ 85743-7796, United States of America

Licensee: Alicat Scientific 7641 N Business Park Dr Tucson AZ 85743-7796, United States of America

Product: Alicat IS-Max and Alicat IS-Pro Pressure and Flow MonitorTrade name(s): Alicat ScientificType(s)/model(s): ISXXX-XX-XX-XX-XX-X

The product and any acceptable variation thereof as specified in the Annex to this certificate and the documents referred to therein.

DEKRA hereby declares that the above-mentioned product has been certified based on:

- an evaluation according to the standard(s) CAN/CSA C22.2 No. 60079-11:2014, CSA C22.2 No. 60079-0:2019, UL 60079-0:2019 and UL 60079-11:2013
- an inspection of the factory location according to DEKRA's North American Certification Scheme
- a DEKRA certification agreement with the number 6066386

DEKRA hereby grants the right to use the DEKRA certification mark as shown below.

The DEKRA certification mark may be applied to the product as specified in this certificate for the duration and under the conditions of the DEKRA certification agreement.

This certificate is issued on 25 April 2025 and expires upon withdrawal of one of the above mentioned standards.

Certificate number: 40-127215

DEKRA Certification B.V.

B.T.M. Holtus Managing Director

© Integral publication of this certificate is allowed

DEKRA CERTIFICATION B.V. IS NRTL RECOGNIZED BY OSHA AND ACCREDITED BY THE STANDARD COUNCIL OF CANADA

Henk Schendstok Certification Manager



DEKRA Certification B.V. Meander 1051, 6825 MJ Arnhem P.O. Box 5185, 6802 ED Arnhem, Netherlands T +31 88 96 83000 F +31 88 96 83100 www.dekra.nl Company registration 09085396

DEKRA



ANNEX TO cDEKRAus CERTIFICATE 40-127215

page 1 of 3

SPECIFICATION OF THE CERTIFIED PRODUCT

Product data Product Trade name(s) Type(s)/model(s) (Canadian Zones) (U.S. Zones) (U.S. Zones)Class I, Zone O, Acking IIC 14 Ga(Canadian & U.S. Divisions): Class I, Division 1, Groups ABCD T4, Ex iaIngress protection / Enclosure Type: IP 66 (based on IEC 60529), TYPE 4XRated ambient temperature range: -20 °C to +70 °C (°C)

- : Alicat IS-Max and Alicat IS-Pro Pressure and Flow Monitor
- : Alicat Scientific : ISXXX-XX-XXX-XX-XX-X-X
- : Ex ia IIC T4 Ga
- : Class I, Zone 0, AEx ia IIC T4 Ga

TESTS

Test requirements

CAN/CSA C22.2 No. 60079-11:2014 CSA C22.2 No. 60079-0:2019 UL 60079-0:2019 UL 60079-11:2013

Test result

The test results are documented in DEKRA test file 383025800.

Conclusion The examination has confirmed that all requirements were met.

Factory location

Alicat Scientific 7641 N Business Park Dr

Tucson AZ 85743-7796, United States of America



Standards electrical safety

The product has been certified on the basis of an evaluation according to the standards CSA C22.2 No. 61010-1-12 and UL 61010-1:2012.

Description

Model designations beginning with **ISMC**, **ISLC**, **and ISPC** include one or two control valves. All other model designations do not. The MAIN board is unchanged between all variants. Some Variants may, optionally, omit a display as noted in the type designation/part numbering system below.

All variants are intended to be connected to fluid processes. All devices measure the process pressure and ambient conditions. Some devices may additionally measure process humidity and temperature to provide additional information or provide additional corrections or control. Variants with control valves may modulate those valves to control the pressure of or flow rate through attached plumbing.

Multiple interfaces are available in the range of serial (RS485 or RS232), analog (4-20mA in/out) discrete inputs, as well as an optional display and keypad. Each of the interfaces require a barrier, except, potentially the discrete inputs, which may be serviced by a switch closure with no additional energy limitation.

Type designation

ISXXX-XX-XX-XX-XX-XX-XX-X (where 'X' represents alphanumeric designations of part configuration). An extended description of the part numbering system and how model designations affect the installation of the device is included at the end of this document.

Thermal data

Rated ambient temperature range (°C): -20 °C to +70 °C External sources of heating (process gas temperature) are considered in the temperature assessment. Installation instructions mandate that the process fluid cannot exceed the -20 to +70°C ambient temperature limits.

See drawing 510577 – IS enclosure Back Label Refer to: DOC-MANUAL-IS-SAFEINSTALLATION

Electrical data

Refer to: DOC-MANUAL-IS-SAFEINSTALLATION



ANNEX TO cDEKRAus CERTIFICATE 40-127215

page 3 of 3



Signal Name	Function	Circuit on control diagram.	Connector Pin	Signal Return Pin	Ui/Vmax	Pi	Ш	Ci	Li	Uo/Voc	Ро	lo/lsc	Co	Lo	
Main Power Input	Main Module Power	A	10	9	12.1 2.02 1.2 0.9 0.12	Internally Limited	3.33A 2.02A 1.2A 0.9A 0.12A	0	0	0	0	0	Blocked	With Infallible Diodes†	
Valve Power Input	Valve Solenoid Power	В	1	2	12.1 2.02 1.2 0.9 0.12	Internally Limited	3.33A 2.02A 1.2A 0.9A 0.12A	0	0	0	0	0	Blocked	Blocked With Infallible Diodes†	
RS-232 RX+TX or RS485A+B	Serial Interface to signal Return	¢★	8+15 to return	13	15V 28V	0.4W 0.9A 0.12A		0	0	6.44V	598mW	723mA	25µF	68µH	
RS-485 A+B	Serial interface to isolated	C∳	8 to 15 or 15 to 8	none	28V 15V	0.4W 0.12A 0.9A		0	0	6.44V	285mW	177mA	25µF	1.135mH	
Remote Tare Aux Discrete 1 Aux Discrete 2	Discrete Switch Inputs	D	14 4 3	11	28V	Blocked V Infallible Die		0	0	10V	74mW	16.2mA	0.75µF	135.5mH	
Analog Signal In	4-20mA, 0-5V, or 0-10V input	E	12	11	28V	0.651W	93mA	0	0	10V	74mW	16.2mA	0.75µF	135.5mH	
4-20mA Power In	4-20mA Power Input	F	6	5	28V	0.651W	93mA	0	0	0	0	0	Blocked	l with Infallible Diodes†	
4-20mA Out	4-20mA Signal out	F	7	5	28V	Blocked V Infallible Die		0.0139µF	0	‡ 6.51V or Barrier Uo into Pin 6	‡ 1.1mW plus Barrier Po into Pin 6	‡ 0.66mA plus Barrier Io/Isc into Pin 6	0.069µF	0.069µF 4.023mH	
♦ Use these parameter † Blocked with Infallibl ‡ The 4-20mA out interf	Each instrument is configured exclusively for RS232 or RS485 by internal jumpers. Use these parameters when using a barrier that is referenced to signal return. Use these parameters for RS485 with a 2-wire an isolated barrier that is not referenced to signal return. Blocked with Infallible Diodes: Three suitably rated series diodes are used internally to only allow current in one direction and block all return current. For any such labelled parameter, the The 4-20mA out interface is recomended for an isolated repeater that supplies loop power into pin 6. The loop power is applied to pin 6 and then supplied back out of the interface via pin 7 as a regulated 4-20mA current with the same max voltage as the input. Without the connection of the external barrier, the 4-20mA Barrier Out (Connector pin 7) has Uo/Voc=5V51, Io/Is=0.66mA, Po=1.1mW.														

CONTROL DRAWING: RECAPITULATED FROM DOC-MANUAL-IS-SAFEINSTALLATION REV 3

TABLE 01 - SUMMARY OF INDIVIDUAL ENTITY PARAMETERS

THE USER IS PERMITTED TO UTILIZE THE SUMMARY OF INDIVIDUAL ENTITY PARAMETERS IN TABLE 01 OF THIS DOCUMENT TO INTERPRET ADDITIONAL CONFIGURATIONS OF BARRIERS NOT SHOWN IN THE EXAMPLE CONFIGURATIONS. THE ENTITY CONCEPT MUST BE FOLLOWED. THIS IS THE RESPONSIBILITY OF THE INSTALLER TO INVOLVE PERSONNEL SKILLED IN MAKING THE ASSESSMENT. (REF IEC 60079-14 A.2)



page 5 of 6

SIGNAL NAME	SIGNAL FUNCTION	CONTROL DIAGRAM CIRCUIT	CONNECTOR PIN	SIGNAL RETURN PIN	Ui/Vmax	Pi	li	Ci	Li	Uo/Voc	Ро	lo/lsc	Co	Lo
RS-232 RX+TX	SERIAL	C*	8+15 to	13	0-15V	Resistance Limited	0.9A	0	0	6.44V	200mW	125mA	25µF	2.27mH
or RS485A+B	to signal Return		return		15-28V	0.4W	0.12A							
RS-485 A+B	SERIAL INTERFACE	C�	8 to 15 or		0-15V	Resistance Limited	0.9A	0	0	6.44V	37mW	23mA	25µF	67mH
	to isolated barrier		15 to 8		15-28V									
★ Each Instrumer	★ Each Instrument is configured exclusively for RS-232 or RS-485 by internal jumpers. Use these parameters when using a barrier that is referenced to signal return.													
Use these parar	neters for RS-485 wit	th a 2-wire i	isolated barri	ier that is	not referen	ced to signal retu	m							

These parameters do not apply to parts with a "2" or a "4 in the top level part number.

Entity parameters for circuits A, B, D, F are found in Table 01.

TABLE 02 — RS-232 AND RS-485 ENTITY PARAMETERS FOR DEVICES WITH A '3' OR AN '8' IN THE TOP LEVEL PART NUMBER.



THE IS-Max or IS-Pro DESIGN IS SUCH THAT THE INTERFACES MAY BE GROUPED INTO THREE (3) SEPARATE INTRINSICALLY SAFE CIRCUITS CONSISTING OF CIRCUIT A, CIRCUIT B AND THE SUM OF THE CIRCUITS C, D, E AND F. THE SEPARATE CIRCUITS MAY ALSO BE COMBINED WHERE THE ASSOCIATED BARRIER(S) FIT WITHIN THE ENTITY PARAMETER CALCULATIONS.

THE ENTITY PARAMETERS FOR THE POWER CONNECTIONS ARE DEFINED IN TABLE 1, CIRCUITS A AND B. MAIN POWER (CIRCUIT A) IS ALWAYS NECESSARY. VALVE POWER (CIRCUIT B) IS OPTIONAL IN THE CASE OF A METER ONLY DEVICE. CIRCUIT A AND CIRCUIT B ARE SERVED BY SEPARATE BARRIERS OR CAN BE BOTH SUPPLIED BY A SINGLE BARRIER. FOR <15V. POWER IS INTERNALLY LIMITED PER THE SAFETY CONCEPT. FOR 15-28V, THE BARRIER POWER IS RESTRICTED TO 1.25W PER THE SAFETY CONCEPT.

12V MAXIMUM IS RECOMENDED FOR BEST VALVE PERFORMANCE (NOT A SAFETY REQUIREMENT).

THE ENTITY PARAMETERS FOR THE SERIAL CONNECTIONS ARE DEFINED IN TABLE 1 CIRCUIT C. EACH INSTRUMENT IS FACTORY CONFIGURED EXCLUSIVELY FOR RS232 OR FOR RS485 BY INTERNAL JUMPERS.

WHEN THE BARRIER IS RS485 AND HAS NO COMMON RETURN (ISOLATED), THE ENTITY PARAMETERS ONLY APPLY BETWEEN THE SIGNAL CONDUCTORS AND NOT TO RETURN.

THE ENTITY PARAMETERS FOR THE DISCRETE INPUT CONNECTIONS ARE DEFINED IN TABLE 1, CIRCUIT D THESE SIGNALS ARE NOT REQUIRED TO BE SEPARATE INTRINSICALLY SAFE CIRCUITS FROM ANY OTHER CIRCUIT ON THE SIGNAL CONNECTOR. SIGNALS ARE ACTIVATED BY CONNECTION TO RETURN. THIS COULD BE A SIMPLE SWITCH CONTACT OR AN INTRINSICALLY SAFE RELAY OR DISCRETE OUTPUT BARRIER. THE SIGNALS ARE DIODE BLOCKED AND THUS PROTECTED FROM AN EXTERNAL Um. THESE SIGNALS MAY HAVE ENTITY PARAMETERS COMBINED WITH OTHER SIGNALS IN THE SAME DEVICE.

ENTITY PARAMETERS FOR THE ANALOG INPUT CONNECTION IS DEFINED IN TABLE 1, CIRCUIT E. THE 4-20mA/0-5V/0-10V INPUT IS SOFTWARE SELECTED FOR VOLTAGE OR CURRENT. HOWEVER THE SELECTION DOES NOT AFFECT THE ENTITY PARAMETERS.

THE 4-20mA POWER IN/SIGNAL OUT CIRCUIT (CIRCUIT F) ACCEPTS POWER FROM A BARRIER (PIN 6), PROVIDES DIODE ISOLATION, ADDS 4-20mA CONTROL, AND DELIVERS THE CURRENT BACK OUT ON PIN 7. FOR THE EVALUATION OF ENTITY PARAMETERS. THE OUTPUT Uo/Voc. Io/Isc. Po FROM PIN 7 IS <= THE ENTITY PARAMETERS OF THE BARRIER CONNECTED TO PIN 6.



L/R VALUE NEED NOT BE ASSUMED OR INFERRED.

page 7 of 6

GENERAL NOTES:

1. CONTROL EOUIPMENT CONNECTED TO BARRIER MUST NOT USE OR GENERATE MORE THAN 250V

- 2. APPROVED BARRIERS MUST BE INSTALLED IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.
- 3. THIS IMPLEMENTATION UTILIZES A CABLE CONTAINING MORE THAN ONE INTRINSICALLY SAFE CIRCUIT (REF IEC 60079-25 8.3). USE ONLY ALICAT SPECIFIED CABLE. THE ALICAT SPECIFIED CABLE IS IN ACCORDANCE WITH THE REQUIREMENTS OF A MULTI-CIRCUIT CABLE TYPE A OR TYPE B, AS SPECIFIED IN IEC 60079-14. THE ALICAT SUPPLIED CABLE IS CONSTRUCTED WITH SOLID INSULATION PER IEC 60079-11 EDITION 6 TABLE 5, FOR <30V, WHERE APPROPRIATE SEPARATION IS APPLIED IN ORDER TO FACILITATE CERTIFICATION WITH MULTIPLE INTRINISCALLY SAFE CIRCUITS IN ONE CABLE.
- 4. THE ALICAT SUPPLIED CABLE FOLLOWS THE MAXIUM ENTITY VALUES OF 550pF/meter, 1μH/meter and 5.3μH/Ω. WHERE A BARRIER OMITS A PARAMETER, THAT PARAMETER IS NOT REQUIRED. FOR EXAMPLE, A CERTAIN IS POWER SUPPLY CERTIFCATE STATES A MAXIMUM VALUE FOR L/R WITHOUT STATING L. THIS MEANS THAT ONLY L/R NEEDS TO BE CONSIDERED AND AN EQUIVALENT L VALUE NEED NOT BE ASSUMED OR INFERRED. LIKEWISE, ANOTHER IS POWER SUPPLY CERTIFICATE STATES L WITHOUT STATING L/R. IN THIS CASE AN EQUIVALENT
- 5. ALL SIGNAL RETURNS ARE CONNECTED TOGETHER INTERNAL TO THE IS-Max or IS-Pro. THE INTERNAL CONNECTIONS ARE ISOLATED FROM CHASSIS. AS A RESULT, EXTERNAL VOLTAGES DO NOT NEED TO BE SUMMED.
- 6. ALL WIRING MUST RUN SEPARATELY IN THE ALICAT SUPPLIED CABLE AND TERMINATED AT THE BARRIER(S). MODIFICATION OF THE CABLE (OTHER THAN LENGTH) IS NOT PERMITTED.
- 8. NON-GALVANICALLY ISOLATED BARRIERS MUST BE CO-LOCATED AND MUST TERMINATE SAFETY GROUNDS TO THE SAME PHYSICAL EARTHING CONNECTION OR GROUNDING ROD. SEPARATED GROUNDS ARE NOT PERMITTED.
- 9. WHERE GALVANICALLY NON-ISOLATED BARRIERS ARE USED, THE INSTALLER MUST CONSIDER THAT RETURN CURRENT MAY BE SUMMED FOR ALL NON-ISOLATED BARRIERS (REF IEC 60079-25 ANNEX B). THE SUM OF THE CURRENTS FOR 2 OR MORE NON-GALVANICALLY ISOLATED BARRIERS CANNOT NOT EXCEED IEC 60079-11 TABLE A.2 AT THE VOLTAGE FOR THE HIGHER OR HIGHEST OF THE BARRIERS IN USE. THIS IS THE RESPONSIBILITY OF THE INSTALLER TO INVOLVE PERSONEL SKILLED IN MAKING THE ASSESSMENT. (REF IEC 60079-14 A.2)
- 10. INSTALL PER EN 60079-14, IEC 60079-14, ANSI/ISA-RP12.6, ANSI/NFPA 70 (US NATIONAL ELECTRICAL CODE), CSA C22.1 (CANADIAN ELECTRICAL CODE) (AS APPLICABLE) AND APPLICABLE LOCAL INSTALLATION CODES.
- 11. THE USER IS PERMITTED TO UTILIZE THE SUMMARY OF INDIVIDUAL ENTITY PARAMETERS IN TABLE 01 OF THIS DOCUMENT TO INTERPRET ADDITIONAL CONFIGURATIONS OF BARRIERS NOT SHOWN IN THE EXAMPLE CONFIGURATIONS. THE ENTITY CONCEPT MUST BE FOLLOWED. THIS IS THE RESPONSIBILITY OF THE INSTALLER TO INVOLVE PERSONEL SKILLED IN MAKING THE ASSESSMENT. (REF IEC 60079-14 A.2)
- 12. REFER TO THE ALICAT SCIENTIFIC INSTRUCTION MANUAL FOR ADDITIONAL REQUIREMENTS AND APPLICATION EXAMPLES.
- 13. WARNING SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY. AVERTISSEMENT: LA SUBSTITUTION DE COMPOSANTS PEUT COMPROMETTRE LA SÉCURITÉ INTRINSÈQUE.
- 14. WARNING: EXPLOSION HAZARD DO NOT DISCONNECT EOUIPMENT UNLESS PRIMARY POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZAROUS



Intrinsically Safe "IS-Pro & IS-Max" Part numbering system:

Example Part	ISPC ·	- N	E	- F	Ν	В	-	2	D	1	X	X	-	000	- P01
# Description:	Model Designator	Native - Range Magnitude	Native Range Units	Seal - Material	Port Threads	Port Size (Dash Size)	-	Serial Protocol	Display	_	2nd Sensor	O ₂ Clean	-	Upstream Valve	- Downstrea m Valve
Model #s	ISM = Mass flow meter ISMS = Mass flow meter, Media-isolated sensor ISMQ = High-pressure mass flow meter ISMW = Low-pressure-drop mass flow meter ISMC = Mass flow controller ISMCS = Mass flow controller ISMCS = Mass flow controller, Media-isolated- sensor ISMCQ = High-pressure mass flow controller ISMCW = Low-pressure-drop mass flow controller ISL = Liquid flow meter ISLC = Liquid flow controller ISP = Pressure gauge ISPS = Pressure gauge, media-isolated sensor ISPC = Pressure controller ISPCS = Pressure controller, media-Isolated sensor ISPCD = Closed volume or dual-valve pressure	Magnitude A = 0.5 B = 1 E = 2 F = 5 G = 10 H = 15 I = 20 J = 30 K = 40 L = 50 N = 100 O = 200 P = 250 Q = 500 R = 1000 T = 1500 Y = 3000 Z = 5000 X = None or External Sensor	A = SCCM B = SLPM C = CCM D = LPM E = PSIA F = PSIG G = PSID J = PSIA, remote port K = PSIG, remote Port X = None or External Sensor	F = FKM K = FFKM E = EPDM A = Silicone U = USP FKM L = Low- Temp FFKM	N = NPT D = NeSSI G = BSPP J = SAE R = VCR Q = VCO M = Metric S = Compression Z= 90° NeSSI	Size) A = $\frac{1}{16}$ " (1) B = $\frac{1}{8}$ " (2) C = $\frac{1}{4}$ " (4) D = $\frac{3}{8}$ " (6) E = $\frac{1}{2}$ " (8) F = $\frac{5}{8}$ " (10) G = $\frac{3}{4}$ " (12) H = 1" (16) I = $\frac{1}{4}$ " (20) J = $\frac{1}{2}$ " (24) K = 2" (32) L = NeSSI M = SMM/M5 N = 6mm O = 10mm P = 12mm Q = 18mm		3 = RS232 (Updated) 8 = RS485 (updated) 2 = RS232 (Depecrated) 4 = RS485 (Depecrated)	X = None D = LCD		X = None T = Temperature R = Humidity Y = Both	X = None U= O ₂ Cleaned H= HLC Cleaned. [Reserved for other cleaning or surface treatment options]		000 = No Valve P01 = Brass/ FKM .003" P02 = Brass/ FKM .010" P03 = Brass/ FKM .030" P04 = Brass/ FKM .050" P05 = Brass/ FKM .065" P06 = Brass/ FKM .070" P07 = Brass/ FKM .000" S01 = Steel/ FFKM .003" S02 = Steel/ FFKM .010" S03 = Steel/ FFKM .050" S05 = Steel/ FFKM .065"	See upstream



ANNEX TO cDEKRAus CERTIFICATE 40-127215

page 9 of 6

ISPCDS = Closed volume or dual-valve pressure							
controller, media-Isolated							
sensor							

Example Part #s and interpretation:

ISMC-NB-FJC-2D-XX-P07-000 = 100 SLPM Mass flow controller, FKM process Seals, ¹/₄" SAE4 Ports (7/16-20 thread), RS-232. 0.200" Orifice brass/FKM upstream valve.

ISPCD-JE-ANB-2D-TU-P04-P05 = 30PSIA dual valve pressure controller, silicone process seals, 1/8" NPT Ports, RS-232, Display, Secondary Temperature Sensor, O2 Cleaning service, 0.050" Brass/FKM upstream valve, 0.065" Brass/FKM downstream valve



1 Detailed description of model differences:

The model designation system for Alicat IS devices provides for hundreds of thousands of possible parts. Type testing was performed on subassemblies in the most onerous configurations for each to ensure that any possible model variations meet the minimum construction and ignition safety requirements of an intrinsically safe device. The descriptions below provide specific information on which model designations affect the way the device operates as is relevant for an installation.

1. Model Designation:

Part number example: ISPCD-JE-ANB-2D-TU-P04-P05

The model designation begins with the 2-character combination "IS" for all devices. The third character of the model designation is either "**M**", "**P**", or "**L**".

- "ISM" designates an IS-Max device. "M" models are gas mass-flow devices which use three sensors to calculate mass flow rates.
- **"ISL**" designates an IS-Max device. **"L"** models are liquid/volumetric flow meters. These use three media-isolated sensors ported to the process to calculate water flow rates. Media-isolated sensors are electrically separated from the process by a thin steel membrane which covers a silicone filled drum. Pressure on the membrane transmits pressure to a sensor element hydraulically.
- **"ISP**" designates an IS-Pro device. **"P**" models typically port a single pressure sensor to the process for pressure feedback or control. P models may also be configured with no internal sensors, instead substituting an external 4-20mA current signal for the primary sensor signal.

The Model designation may have a fourth and fifth letter designating the presence of valves.

- A "C" indicates a controller with a single valve
- A "C" followed by a "D" indicates a controller with two valves. This configuration is only valid for pressure controllers.

An optional, final letter "W", "Q" or "S" designates special sensor configurations.

- **"W"** models are gas mass flow models which use less restrictive flow bodies. They are otherwise mechanically identical to non-W models.
- "Q" models are gas mass flow models which use a sensor with a higher maximum rated pressure.
- "S" models are flow or pressure models which use media-isolated sensors. "ISMS" and "ISMCS" models are mechanically identical to "ISL" devices. "ISPS/ISPCS/ISPCDS" models use media isolated sensors which are rated for higher pressures (3000 psi/205bar)
- If "W", "Q" or "S" is not specified the part is constructed with a default sensor package.

Model designation differences affect the installation of, and the intrinsic safety of the device as follows:

- Models with included valves require an additional barrier to power those valves as denoted by "CIRCUIT B" in Figure 01 of the control drawing.
- Models intended for use with external sensors will connect those sensors to the analog input denoted by circuit E in Figure 01 of the control drawing. These



sensors must obey the entity parameters appropriate for circuit E/ Table 01 of the control drawing or use an intervening barrier which does.

2. Native Range/Unit Designation

Part number example: ISPCD-JE-FNB-2D-TU-P04-P05

The native range portion of the model number is 2 characters long. The first character designates a number ranging from 0.5 to 5000 and the second character designates the base unit of measure. Native range model designations vary in size and mounting options.

Model differences in native range do not change the intrinsically safe properties or installation requirements of the device.

3. Seal Material Designation

Part number example: ISPCD-JE-<u>F</u>NB-2D-TU-P04-P05

Seal material is designated by a single character in the part numbering scheme. EUT Models which have different seal material designations are built with different elastomer gasket material at the pressure boundary, but not for the enclosure. All elastomers used are rated for at least the same range of operating temperatures as the device.

Model differences in seal material do not change the intrinsically safe properties or installation requirements of the device.

4. Port type and port size Designation

Part number example: ISPCD-JE-F<u>NB</u>-2D-TU-P04-P05

The type and size of threaded process ports machined into the EUT is designated by these two letters in the part number. The first letter designates a style and the second a nominal fitting/pipe size. A dash size is included in parenthesis in the reference table as an alternative standard for denoting fitting size. Model designations with a port size larger than the safe dimensions of the flow body and mounting screws are not valid. Pressure EUT models which are designated with ports larger than 0.25 will use the high-flow variant of the flow body. High flow variants are limited to pressures below 305psi (21bar).

Model Port type and port size in native range do not change the intrinsically safe properties or installation requirements of the device.

5. Serial interface Designation

Part number example: ISPCD-JE-FNB-<u>3</u>D-TU-P04-P05

A **3** or an **8** at this location in the part number designates which serial protocol a device is configured for. Options are either RS-485 or RS-232. The serial protocol is selected by changing the position of three jumpers on the main circuit board.

A 2 or a 4 at this location reflects an older version of the same interfaces with higher entity output entity parameters.

Models designations for different serial interfaces affect the installation of and intrinsic safety of the device as follows:

Annex 1 to cDEKRAus certificate



- Models denoted ISXXX-XX-XXX-<u>3</u> are RS-232 capable devices. To use the RS-232 interface for digital communication with these devices requires the use of a barrier limited to the entity parameters denoted by C * in table 02 of the control drawing.
- Models denoted ISXXX-XX-XXX-8 are RS-485 capable devices. To use the RS-485 interface requires the use of a barrier which meets the entity parameters denoted by C in table 02 of the control drawing.
- (This part number is deprecated and included only for legacy installations) Models denoted ISXXX-XX-XXX-2 are RS-232 capable devices. To use the RS-232 interface for digital communication with these devices requires the use of a barrier limited to the entity parameters denoted by C★ in table 01 of the control drawing. This part number is deprecated and included only for legacy installations
- (This part number is deprecated and included only for legacy installations) Models denoted ISXXX-XX-XX-<u>4</u> are RS-485 capable devices. To use the RS-485 interface requires the use of a barrier which meets the entity parameters denoted by C� in table 01 of the control drawing.
- Use of a digital communication in a daisy-chain or Bus configuration is possible if the sum of all barrier and cable parameters does not exceed the entity parameters of any connected device and grounding requirements are considered as noted in the General Notes section of the control drawing.
- The serial interface may be disconnected if the end user does not intend to use serial communication by trimming the wires flush and capping or sealing the unused wires as appropriate for local installation practices.

6. Display Designation

Part number example: ISPCD-JE-FNB-2**D**-TU-P04-P05

An "X" or a "D" at this location designates an EUT model with or without an LCD display and front control panel. Devices without a display use a solid anodized aluminum plate in place of the display.

Model differences in the display do not change the intrinsically safe properties or installation requirements of the device.

7. Secondary sensor designation

Part number example: ISPCD-JE-FNB-2D-TU-P04-P05

This portion of the part number is a single character which may designate one or more secondary sensors for a device. A secondary sensor is either a temperature sensor ("T"), a humidity sensor ("H"), or both ("Y"). Not all combinations of sensors may be relevant to all models.

Secondary sensor designations do not change the intrinsically safe properties or installation requirements of the device.

8. Cleaning or Surface Treatment Designation

Part number example: ISPCD-JE-FNB-2D-TU-P04-P05

Model numbers with a "U" in this position undergo a special cleaning process to prepare them for pressurized oxygen service but are otherwise mechanically identical to "X" designated non-oxygen-cleaned devices. This letter may also designate other steel surface treatment options such as polishing or coating which do not affect the type safety of the device.



This designation affects part cleanliness only. It does not change the intrinsically safe properties or installation requirements of the device.

9. Valve Selection designation

Part number example: ISPCD-JE-FNB-2D-TU-P04-P05

The type and location of valves is designated by two 3-character sequences at the end of the part number. The first sequence refers to valves on the left/upstream side of the device, and the second to valves on the right/downstream side of the device. Dual valve pressure controllers (ISPCD models) designate valves at both locations. Software settings are minorly affected by the valve location but not in a way that affects safety functions.

- EUT models with valve designations P01-P05 and S01-S05 use Parker brand "MDPro" series small pneumatic proportional control valves with orifice sizes ranging from 0.003" to 0.065".
- EUT models with the valve designation P06 use Parker "HFPro" series valves, which otherwise have the same external dimensions/form factor as the MDPro valve.
- EUT models with the valve designation P07 use a parker VSO Max high flow valve which has a slightly larger form factor than the other valves.

Valve selection do not change the intrinsically safe properties or installation requirements of the device beyond what is described in the "Model designation" section for controllers which must use a separate barrier.

10. Adder Codes/Software configuration codes:

Part number example: ISPCD-JE-FNB-2D-TU-P04-P05 / GAS: XXX, HC, SENIN, RTL, RANGE: XXX... P1/P2 ETC...

All EUTs use a second string of characters after the part number, separated by a forward slash. These are "adder codes". Adder codes designate software configuration options such as calibration and control loop tuning instructions or default configuration settings so that a device is pre-configured for a user's application.

Adder codes are separate from the model designation and do not affect the mechanical construction of or safety of any device.

Specific Conditions of Use

The black metal sections of the enclosure are anodized aluminum and are a potential impact ignition source. Protect the apparatus from impact and abrasion as appropriate for the installation zone.

Certificate history

Project : 383025800 initial certificate